

IP65 rated high powered LED highbay light

Instruction Sheet - Lens Swap

PHOEBE LED


Instructions



Take a note of where all 13 lens clips are holding it to the base of the fitting.



Top view of the clip









Apply force to the tab until it comes away from the clip on the base.



Once the Clips on the outer-edge are loose, pull away slightly from the base using a screwdriver.




O Crompton Lamps Limited Unit 2, Marrtree Business Park Bowling Back Lane Bradford BD4 8QE

01274 657 088

01274 657 087








Use a screwdriver to apply force to the three middle tabs until they come away from the base.



With a small amount of force, the lens should now come away from the base.





Remove both the inner and outer IP65 rings from the old lens to install on the new fitting

Note – warranty is void if this step is missed.



Crompton Lamps Limited Unit 2, Marrtree Business Park Bowling Back Lane Bradford BD4 8QE



01274 657 087













Push the inner IP65 ring onto the mount rail on the base and push down firmly







Push the outer IP65 ring onto the mount rail on the base and push down firmly.



Both rings installed



Crompton Lamps Limited Unit 2, Marrtree Business Park Bowling Back Lane Bradford BD4 8QE 01274 657 088

01274 657 087

info@cromptonlamps.com













Ensure the space for the connection terminals on the new lens is lined up with the terminals on the LED board, and lower into place.

Secure the outer edge clips. Listen for the audible 'click' to indicate correct lock.



Then likewise with the inner edge clips.



The new completed unit is ready to install.



Crompton Lamps Limited Unit 2, Marrtree Business Park Bowling Back Lane Bradford BD4 8QE





info@cromptonlamps.com

