VERONA BULKHEAD

Emergency Kit instructions - Self Test mode

Technical Instructions

Function Test

The function test is carried out every month for a duration of 3 minutes. It will check the connection of battery, battery discharging and the connection of LED module. Any issues found will be confirmed by the indicator LED.

Duration Test

An initial duration test is carried out at first power on, but after 24 hours charging. The yearly duration test is carried out for 3 hours on one day within the 300th day to the 365th day of each subsequent year. It will also check the connection of battery and LED module. Any issues found will be confirmed by the indicator LED.

Indicator LED Functions

A bi-colour indicator will indicate the normal and abnormal status. Green is for conditions are normal and red for the faulty conditions.

LED Colour	Status		Description
Green		Permanent on	Normal status when mains connected
		Slow flash	Duration test running
	\otimes	Fast flash	Function test running
		Normal flash (three times only)	Time reset
Red		Permanent on	Battery failure
		Slow flash	Lamp/LED failure
		Fast flash	Duration failure - the capacity of the battery is not enough – Please charge.
Off	\bigcirc	Off	Emergency mode or power failure if main light is off.

A test switch is applied for different functions activated manually.

Duration	Function		
Press for <2s	Simulate emergency mode		
Press for 3-5s	Start duration test manually. The test can be aborted by pressing off (1-2s).		
Press for 5-8s	Start Function test manually for 60s.The test can be aborted by pressing off (1-2s).		
Press for >10s	Time Reset – Next test will be 300 to 356 days from now.		

What to find out more?

Check out more info at cromptonlamps.com



Scan for more information online

€ 01274 657 088
☐ 01274 657 087
☑ info@cromptonlamps.com
⊕ cromptonlamps.com

Crompton Lamps Limited Unit 2, Marrtree Business Park, Bowling Back Lane, Bradford, BD4 80F



